

# Professional Auto Air Conditioning Dispensing Valve for R-134a Can

---

- **Brass Construction for Durability & Safety**
  - **Fits All R-134a Service Hoses**
- 

For correct charging procedure consult appropriate instructions and equipment manufacturer's service manual

## **Instructions for connection of Dispensing Valve to can:**

- 1.** Open valve stem to raise piercing pin.
  - 2.** Thread valve onto top of can in clockwise direction.
  - 3.** Make appropriate connection of manifold hose to dispensing valve and air conditioning service ports.
  - 4.** When ready to change air conditioner system depress piercing pin, then back off to open valve.
  - 5.** Turn handle down to close off valve.
- 

**Use with Interdynamics R-134a Manifold  
Gauge, Hoses and Quick Connectors**

---